1. Set static IP for sMS-200 what you want. e.g. below:
    - IP - 10.0.0.2
    - subnet - 255.255.255.0
    - gateway - 10.0.0.1
2. Set static IP for your PC, too. e.g. below:
    - IP - 10.0.0.1
    - subnet - 255.255.255.0
    - gateway - empty

ref.: http://www.online-tech-tips.com/computer-tips/windows-mac-assign-static-ip-address/

From:
https://docs.sotm-audio.com/ - **SOtM docs**

Permanent link:
https://docs.sotm-audio.com/doku.php?id=en:kb:direct_connection&rev=1500444674

Last update: **2026/11/17 03:29**