Precaution

Please read this instruction carefully before use.

- Do not attempt to disassemble or modify the product.
- Keep the product away from the external shocks or vibrations.
- Do not use the damaged or peeled cables.
- Do not use the product outdoors.
- Product specifications and features are subject to change without notice.

Warranty Information

- Free warranty service
 - In case of the defect is found caused by the design or the production flaw while using the device properly, a manufacturer is responsible for the faulty product and the free warranty service for 1 year from the date of purchasing.
 - Even in the warranty service period, malfunction or damage of products caused by the inevitable incident such as a natural disaster is not subject of the free warranty service.
- Warranty service at a cost
 - The product that free warranty service period is expired.
 - Malfunction of the product caused by a user's fault.
 - Malfunction of the product caused by incidents.
 - Malfunction of the product caused by a natural disaster such as earthquake, flood, lightning & etc.
 - In case of the warranty service at a cost, a customer should cover the transportation costs.
- Examples about an user's fault
 - In case of attempts to disassemble or modify the device.
 - In case of not following the instructions on this manual.
- Please read this operating instructions and Q&A board on our website carefully before asking for the warranty service.

Supplied components

- A sNH-10G unit
- An operating instruction



Ultimate High Performance Audio

Specification

User interface

Power indicator LED x 1

Link indicator Front LED x 10, Rear LED x 8

Active indicator Front dual Color LED x10, Rear LED x 8

Power switch: Power off, Power on with LED or without LED

■ Network

Supported Standards

IEEE 802.3 10Base-T Ethernet

IEEE 802.3u 100Base-TX Fast Ethernet

IEEE 802.3u 100Base-FX 100Mbps over fiber optic

IEEE 802.3ab 1000Base-T Gigabit Ethernet

IEEE 802.3z 1000Base-T 1 Gbps over fiber optic

IEEE 802.3x flow control and backpressure

Full-duplex and half-duplex operation

Supports 9216 byte jumbo packet length

Connector

RJ-45 ports x 8

SFP ports x 2

Optional audio grade clock

sCLK-EX with 10MHz Master clock input

DC power input

Input voltage : 9Vdc

Optional 12Vdc when installing sCLK-EX

Optional 6.5Vdc ~ 8.5Vdc when installing sCLK-EX

Voltage tolerance: ±10%

Input current : 2A max

5.5mm OD, 2.1mm ID adaptor jack

Operating environment

Operating temperature : $+10 \sim +30^{\circ}$ C Storage temperature : $0 \sim +40^{\circ}$ C


Operating & storage humidity : 10% \sim 90%

Dimension

296 x 211 x 50(mm)

■ Weight

2 Kg >



- $\ensuremath{\textcircled{1}}$ A power indicator LED lamp.
- 2 The operation indicator LED lamps indicate the operation status of the LAN port 1 to LAN port 10 from left to right.
 - ⓐ Link & Active LED (Green): Light according to the connection status and operation status of the LAN ports.
 - (b) 100M/1G connections (Red orange/ Amber yellow): Light in Red orange when connecting 100M, in Amber yellow when connecting 1G.
- 3 A 3 steps power on/off switch. Depending on each position of the switch, it works as follows

Upper position: Power on and light the LED lamps.

Middle position: Power off.

Lower position : Power on.

- ④ A DC power input connector.
- The LAN port 1 to LAN port 8 from left to right.
- 6 The SFP port 9 and SFP port 10 are SFP port that is able to connect with optical cables. The connections can be made with SFP modules and optical cables.

Precautions

- When connecting cables, power off the devices which will be connected to the sNH-10G.
- The sNH-10G does not have the network management function like IP allocation, fixed IP, or etc, so it should be used with a router or a device which has the network management functions like the example below.

