

- sDP-1000EX Main Audio USB
- 2가

가

# sDP-1000EX

## Main

- sDP-1000EX Main

[sDP-1000Ex\\_V2.1\\_20190705.zip](#)

- Flip

[Flip 3.4.7 software](#)

## sDP-1000EX

sDP-1000EX PC USB  
DFU

sDP-1000EX Audio USB

- OLED
- OLED




# Flip

Flip , Flip



, AT90USB1286



USB Port Connection 'Open'



'Load Hex File



'Run'



- 가 , sDP-1000EX Audio USB
- Audio
- Audio , OLED가
  - , OLED ,



## Audio USB

- Audio USB

[app\\_usb\\_aud\\_l1\\_2xoxs\\_v6.c2.bin](#)

- SotM 가

[SotM USB Audio 2.0 Driver v2.23.0](#)


## SotM USB Audio Firmware Upgrade

1. sDP-1000EX PC USB
2. Windows OS

sDP-1000EX  
SotM USB Audio Firmware Upgrade



### 'Browse



### 'Start'



가 , SOTM USB Audio Control Panel sDP-1000EX



### sDP-1000EX FW

- [sDP-1000Ex\\_V2.1\\_20190705.zip](#)
- [app\\_usb\\_aud\\_l1\\_2xoxs\\_v6.c2.bin](#)
  
- [Flip 3.4.7 software](#)
- [SOTM USB Audio 2.0 Driver v2.23.0](#)

Last update: 2019/08/13 05:22 ko:how\_to\_upgrade\_sdp-1000ex\_fw [https://docs.sotm-audio.com/doku.php?id=ko:how\\_to\\_upgrade\\_sdp-1000ex\\_fw&rev=1565688129](https://docs.sotm-audio.com/doku.php?id=ko:how_to_upgrade_sdp-1000ex_fw&rev=1565688129)

---

From: <https://docs.sotm-audio.com/> - **SOtM docs**

Permanent link: [https://docs.sotm-audio.com/doku.php?id=ko:how\\_to\\_upgrade\\_sdp-1000ex\\_fw&rev=1565688129](https://docs.sotm-audio.com/doku.php?id=ko:how_to_upgrade_sdp-1000ex_fw&rev=1565688129)

Last update: **2019/08/13 05:22**

