

- SMS-200 V0.3.0 SMS-1000SQ Eunhasu V0.3.0
- Wifi dongle
 - RTL8812AU

Simple Instruction


USB

Wifi USB





[System config](#)

'Wifi'





'Wifi Router'






'Connect'






IP



'Remove Wifi Information'

AP 가



• Eunhasu V0.3.0
 가
 가

From:
<https://docs.sotm-audio.com/> - **SOTM docs**

Permanent link:
https://docs.sotm-audio.com/doku.php?id=ko:how_to_use_wifi_in_eunhasu&rev=1484880969

Last update: **2017/01/19 21:56**