

Roon

Roon

가

. Control, Output, Core

Roon

Roon Ready


Roon Ready Roon Server, Roon Remote

. Roon Ready

RoonBridge

. hqplayer_naa

Roon Ready config



- **Audio device config:** USB DAC
- **Volume mode:** Fixed, Software, Device Controls
- **DSD mode:** DSD NONE, NATIVE, DOP, DCS, NATIVE/DOP, NATIVE/DCS
- **DSD rate:** DSD x64, x128, x256
- **Buffer duration:** 가

- **Resync delay:** 0.1 ~ 0.5 0.01

Roon Ready


Roon Ready
Ready

'Active'
SMS-200

Roon Desktop


Setting > Audio

Roon





Audio Zone





Roon Server


Roon Server Roon Core Roon Output

Roon Remote

[Roonlabs](#)

Roon Server

[Roon Server](#)




[Roon Server](#) 가 (Active)

Roon Desktop Core SMS-1000SQ Core



Core





Audio Zone



: 2017/01/25 00:23

From:
<https://docs.sotm-audio.com/> - **SOTM docs**

Permanent link:
<https://docs.sotm-audio.com/doku.php?id=ko:roon&rev=1485321800>

Last update: **2017/01/25 00:23**

