

Roon

Roon

가

. Control, Output, Core

Roon

Roon Ready


Roon Ready Roon Server, Roon Remote

. Roon Ready

RoonBridge

. hqplayer_naa

Roon Ready config




- **Audio device config:** USB DAC
- **Volume mode:** Fixed, Software, Device Controls
- **DSD mode:** DSD NONE, NATIVE, DOP, DCS, NATIVE/DOP, NATIVE/DCS
- **DSD rate:** DSD x64, x128, x256
- **Buffer duration:** 가

- **Resync delay:** 0.1 ~ 0.5 0.01



Roon Ready

Remote Roon Server . Roon Ready 'Active' . Roon
Settings > Audio Roon Ready SMS-200





sMS-200 Audio zone



Roon Server

Roon Server Roon Core Roon Output

Roon Remote

[Roonlabs](#)

Roon Server

Eunhasu

Roon Server

'Active'




Roon Server 가 'Active'

Roon Desktop



Core

sms-1000SQ

Core



Core



Audio Zone



: 2017/01/25 19:22

From:
<https://docs.sotm-audio.com/> - **SOTM docs**

Permanent link:
<https://docs.sotm-audio.com/doku.php?id=ko:roon&rev=1485390136>

Last update: **2017/01/25 19:22**

