


sMS-1000SQ



sMS-1000SQ


- Windows Edition
- Eunhasu Edition
- Eunhasu



1. : ON/OFF
2. :
3. : ON


가

- sMS-1000SQu




- 1. : POWER INPUT
- 2. : ON/OFF
- 3. : POWER INPUT
- 4. USB : USB
6.5Vdc ~ 9Vdc, 2A
- 5. USB : USB +5.0v ON/OFF
- 6. USB : USB
- 7. USB : USB
- 8. LAN : LAN
- 9. VGA : VGA
- 10. HDMI : HDMI
- 11. : MIC
- 12. : LINE

- SMS-1000SQd



- 1. AES/EBU : DAC AES/EBU
- 2. : DAC Optical
- 3. : DAC

- SMS-1000SQa



- 1. :
- 2. :
- 3. :
- 4. :

From:
<https://www.docs.sotm-audio.com/> - **SOTM docs**

Permanent link:
<https://www.docs.sotm-audio.com/doku.php?id=ko:sms-1000sq>

Last update: **2017/01/25 21:36**

