This document describes another upgrade instruction for Eunhasu.

By samba share

1. Download upgrade-last.tar file from server
    - sMS-200
2. Copy upgrade-last.tar to Eunhasu samba directory \\eunhasu\mw\data\music
3. Eunhasu page load like http://eunhasu/upgrade.php?upgrade_server=eunhasu/music&force=1
    1. *upgrade_server={EUNHASU_IP}/music* is possible

By USB

1. Format USB to FAT32
2. Change USB label to SOTMDEBUG and it must upper case
3. Download upgrade-last.tar file from server
    - sMS-200
4. Copy downloaded upgrade-last.tar to the USB root directory
5. Make file named run_debug.txt in the USB
6. run_debug.txt file must contain following strings

```
upgrade force
```

7. Remove whole inserted USB stick on sMS-200
8. Insert SOTMDEBUG USB to sMS-200
9. On working, blinking left LED
10. After finish, device shows left LED off

By external utility

- sMS-200 - Refer Here

From:
https://docs.sotm-audio.com/ - **SOtM docs**

Permanent link:
https://docs.sotm-audio.com/doku.php?id=en:how_to_upgrade_another_way&rev=1481011361

Last update: **2026/11/17 03:29**