1. Set static IP for sMS-200.

<e.g>:

- IP - 10.0.0.2
- subnet - 255.255.255.0
- gateway - 10.0.0.1

1. Set static IP for your PC, too.

<e.g>:

- IP - 10.0.0.1
- subnet - 255.255.255.0
- gateway - empty

ref.: http://www.online-tech-tips.com/computer-tips/windows-mac-assign-static-ip-address/

From:
https://docs.sotm-audio.com/ - **SOtM docs**

Permanent link:
https://docs.sotm-audio.com/doku.php?id=en:kb:direct_connection&rev=1546394732

Last update: **2026/11/17 03:29**