

Precaution

Please read this instruction carefully before use.

- Do not attempt to disassemble or modify the product.
- Keep the product away from the external shocks or vibrations.
- Do not use the damaged or peeled cables.
- Do not use the product outdoors.
- Product specifications and features are subject to change without notice.

Warranty Information

- Free warranty service
 - In case of the defect is found caused by the design or the production flaw while using the device properly, a manufacturer is responsible for the faulty product and the free warranty service for 1 year from the date of purchasing.
 - Even in the warranty service period, malfunction or damage of products caused by the inevitable incident such as a natural disaster is not subject of the free warranty service.
- Warranty service at a cost
 - The product that free warranty service period is expired.
 - Malfunction of the product caused by a user's fault.
 - Malfunction of the product caused by incidents.
 - Malfunction of the product caused by a natural disaster such as earthquake, flood, lightning & etc.
 - In case of the warranty service at a cost, a customer should cover the transportation costs.
- Examples about a user's fault
 - In case of attempts to disassemble or modify the device.
 - In case of not following the instructions on this manual.
- Please read this operating instructions and Q&A board on our website carefully before asking for the warranty service.

Supplied components

- tX-USBultra unit
- Operating instruction




Ultimate High Performance Audio

Specification

- User interface
 - Power indicate LED bar
- USB host interface port
 - USB 2.0 Type B connector
- USB output Port
 - Type A USB 2.0 connector x 2
 - USB port power on/off switch x 2
- USB interface chip set
 - USB 2.0 Compliant HUB controller
 - HS(480 Mbps), FS(12 Mbps), LS(1.5 Mbps) support
- Ultra low jitter Clock module
 - sCLK-EX12
 - Optional 10MHz master clock input
- Power input
 - Input voltage : +9Vdc
(Optional input voltage : +12Vdc)
(Optional input voltage : +6.5Vdc ~ +8.5Vdc)
 - Input current : 2A max
 - 5.5mm OD, 2.1mm ID adaptor jack
- USB port output power
 - Output voltage : +5.0V(+0.5V, -0.25V)
 - Over current protection : 0.8A at 20°C
 - Recommend output current : 0.5A >
- Operating environment
 - Operating temperature : +10 ~ +30°C
 - Storage temperature : 0 ~ +40°C
 - Operating & storage humidity : 10% ~ 90%

Product outline



- ① Power indicating LED lamp
- ② USB output port 1 : Connect to USB audio device by USB cable(Type A - to - Type B).
- ③ Power switch of USB output port 1: Switch to ON if the connected USB audio device requires USB power. If not, switch to OFF.
- ④ USB output port 2 : Connect to USB audio device by USB cable(Type A - to - Type B).
- ⑤ Power switch of USB output port 2: Switch to ON if the connected USB audio device requires USB power. If not, switch to OFF.
- ⑥ Power input jack : 6.5Vdc ~ 9Vdc, 2A, is required to operate the unit. (jack size : 5.5mm OD, 2.1mm ID)
- ⑦ USB input port : Connect to USB host device like PC or music server by USB cable(Type A - to - Type B).
- ⑧ Master clock connector : Connect to 10MHz master clock device by 50Ohm BNC cable to sync to a master clock. This connector is only installed when ordering the master clock option.

Precautions

- Recommend using one of USB ports only. If you use both USB ports at the same time, sound quality may degrade.

Product user guide

- SOTM tX-USBultra is a 2 ports USB regenerator/jitter cleaner designed for the best USB audio performance.
- Connect the USB input port to a USB host device like a music server or PC and connect the USB output port 1 or 2 to a USB audio device like a DDC or DAC by USB cable(Type A – to Type B).
- Connect the power supply to the product. (Refer to the required power input in the Specification section)
- A power indicating green LED bar is on once powered up and the product will be automatically recognized and work without the driver installation.
- If the connected USB audio device requires +5V of the USB output port, switch to ON the power switch, if not, switch to OFF.
- If you don't use the product, turn off power by unplugged the power supply.

