

mSD

micro SD

Windows

1. SD (3.0 GB .gz) [new micro SD card image](#)
2. SD (7.9 GB .img)
3. PC [imageUSB](#) ,
4. SMS-200 SD PC

imageUSB

[imageUSB](#) , USB 가 ,
 'Refresh Drives' .



USB

USB



'Browse'



'Write'

SD



1. 가 SD SMS-200
2. SMS-200

SD



The screenshot shows the Windows Disk Management console. At the top, a table lists the system's volumes. Below this, the physical disks are shown with their partitions and file systems. A red box highlights the Disk 1 section, which is a removable drive with a total capacity of 7.45 GB. It contains three primary partitions: a 286 MB primary partition, a 244 MB primary partition, and a 6.88 GB primary partition, followed by 44 MB of unallocated space.

Volume	Layout	Type	File System	Status	Capacity	Free Spa...	% Free
(C:)	Simple	Basic	NTFS	Healthy (B...	59.45 GB	29.60 GB	50 %
(Disk 0 partition 1)	Simple	Basic		Healthy (R...	450 MB	450 MB	100 %
(Disk 0 partition 2)	Simple	Basic		Healthy (E...	99 MB	99 MB	100 %
(Disk 1 partition 1)	Simple	Basic		Healthy (P...	286 MB	286 MB	100 %
(Disk 1 partition 2)	Simple	Basic		Healthy (P...	244 MB	244 MB	100 %
(Disk 1 partition 3)	Simple	Basic		Healthy (P...	6.88 GB	6.88 GB	100 %

Disk	Capacity	Partitions
Disk 0 Basic 59.98 GB Online	450 MB Healthy (Recovery Partition)	99 MB Healthy (EFI System Partition) 59.45 GB NTFS Healthy (Boot, Page File, Crash Dump, Primary Partition)
Disk 1 Removable 7.45 GB Online	286 MB Healthy (Primary Partition)	244 MB Healthy (Primary Partition) 6.88 GB Healthy (Primary Partition) 44 MB Unallocated
CD-ROM 0 DVD (D:)	No Media	

Last update:

2023/08/14 03:20 ko:eunhasu:burn_sdcard_image https://docs.sotm-audio.com/doku.php?id=ko:eunhasu:burn_sdcard_image&rev=1691997648

The screenshot shows the Windows Disk Management utility. At the top, a table lists the system's volumes:

Volume	Layout	Type	File System	Status	Capacity	Free Spa...	% Free
(C:)	Simple	Basic	NTFS	Healthy (B...	59.45 GB	29.60 GB	50 %
(Disk 0 partition 1)	Simple	Basic		Healthy (R...	450 MB	450 MB	100 %
(Disk 0 partition 2)	Simple	Basic		Healthy (E...	99 MB	99 MB	100 %
(Disk 1 partition 1)	Simple	Basic		Healthy (P...	286 MB	286 MB	100 %
(Disk 1 partition 2)	Simple	Basic		Healthy (P...	244 MB	244 MB	100 %
(Disk 1 partition 3)	Simple	Basic		Healthy (P...	6.88 GB	6.88 GB	100 %

The main view shows Disk 0 (Basic, 59.98 GB, Online) with three partitions: 450 MB Healthy (Recovery Partition), 99 MB Healthy (EFI System Partition), and 59.45 GB NTFS (C:). Disk 1 (Removable, 7.45 GB, Online) has four partitions: 286 MB Healthy (Primary Partition), 244 MB Healthy (Primary Partition), 6.88 GB Healthy (Primary Partition), and 44 MB Unallocated. A context menu is open over the 6.88 GB partition, with 'Delete Volume...' highlighted. A red text box on the right says: 'Click right button of mouse Delete Volume 3 patitions of Disk1(MSD CARD) It will be changed to 1 of unallocated disk'.





macOS

1. SD (3.0 GB .gz) new micro SD card image
2. dd-utility <https://www.thefanclub.co.za> github
3. SMS-200 SD PC SD



Start Restore

dd-utility 'Restore' .img



SD





sMS-200

SD

dd-utility

- [imageUSB for Windows](#)
- [dd-utility for macOS](#)

micro SD card

- [Eunhasu V0.4.22](#)
- [Eunhasu V0.5.1](#)
- [Eunhasu V0.5.2](#)
- [Eunhasu V0.5.31](#)
- [Eunhasu V0.5.41](#)

From:

<https://docs.sotm-audio.com/> - **SOtM docs**

Permanent link:

https://docs.sotm-audio.com/doku.php?id=ko:eunhasu:burn_sdcard_image&rev=1691997648

Last update: **2023/08/14 03:20**

