

mSD

micro SD

Windows

1. SD
.(3.0 GB .gz) [new micro SD card image](#)
2. SD
.(7.9 GB .img)
3. PC [imageUSB](#) ,
4. SMS-200 SD
SD PC .

imageUSB

[imageUSB](#) , USB 가 ,
'Refresh Drives' .



USB

USB



'Browse'




'Write'

SD



1. 가 SD SMS-200
2. SMS-200

SD



The screenshot shows the Windows Disk Management console. At the top, there is a table listing disk volumes. Below this, the graphical representation of Disk 0 and Disk 1 is shown. Disk 0 is a Basic disk with a total capacity of 59.98 GB, currently online. It contains three partitions: a 450 MB Recovery Partition, a 99 MB EFI System Partition, and a 59.45 GB NTFS Primary Partition (C:). Disk 1 is a Removable disk with a total capacity of 7.45 GB, also online. It contains three partitions: a 286 MB Primary Partition, a 244 MB Primary Partition, and a 6.88 GB Primary Partition. A 44 MB Unallocated space is also present on Disk 1. A red rectangle highlights the Disk 1 section. At the bottom, a legend indicates that black represents Unallocated space and blue represents Primary partitions.

Volume	Layout	Type	File System	Status	Capacity	Free Spa...	% Free
(C:)	Simple	Basic	NTFS	Healthy (B...	59.45 GB	29.60 GB	50 %
(Disk 0 partition 1)	Simple	Basic		Healthy (R...	450 MB	450 MB	100 %
(Disk 0 partition 2)	Simple	Basic		Healthy (E...	99 MB	99 MB	100 %
(Disk 1 partition 1)	Simple	Basic		Healthy (P...	286 MB	286 MB	100 %
(Disk 1 partition 2)	Simple	Basic		Healthy (P...	244 MB	244 MB	100 %
(Disk 1 partition 3)	Simple	Basic		Healthy (P...	6.88 GB	6.88 GB	100 %

Disk	Capacity	Partition 1	Partition 2	Partition 3	Unallocated
Disk 0	59.98 GB	450 MB Healthy (Recovery Partition)	99 MB Healthy (EFI System Partition)	(C:) 59.45 GB NTFS Healthy (Boot, Page File, Crash Dump, Primary Partition)	
Disk 1	7.45 GB	286 MB Healthy (Primary Partition)	244 MB Healthy (Primary Partition)	6.88 GB Healthy (Primary Partition)	44 MB Unallocated







macOS

1. SD (3.0 GB .gz) new micro SD card image
2. dd-utility <https://www.thefanclub.co.za> github
3. SMS-200 SD PC SD



Start Restore

dd-utility 'Restore' .img



SD





sMS-200

SD

dd-utility

- [imageUSB for Windows](#)
- [dd-utility for macOS](#)

micro SD card

- [Eunhasu V0.4.22](#)
- [Eunhasu V0.5.1](#)
- [Eunhasu V0.5.2](#)
- [Eunhasu V0.5.31](#)
- [Eunhasu V0.5.41](#)
- [Eunhasu V0.5.51](#)
- [Eunhasu V0.5.62](#)
- [Eunhasu V0.5.7](#)
- [Eunhasu V0.5.8](#)
- [Eunhasu V0.5.9](#)
- [Eunhasu V0.6.0](#)

From:

<https://docs.sotm-audio.com/> - **SOTM docs**

Permanent link:

https://docs.sotm-audio.com/doku.php?id=ko:eunhasu:burn_sdcard_image&rev=1753163030

Last update: **2025/07/22 01:43**

